# TOP AND CONSOLE PARTS

**For Models: LER5644JQ0, LER5644JT0**
**(Designer White) (Biscuit)**

ELECTRIC DRYER










FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

**For Models: LER5644JQ0, LER5644JT0**
**(Designer White) (Biscuit)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | LITERATURE PARS |
| | LIT8314844 | Use & Care Guide |
| | LIT3397618 | Installation Instructions |
| | LIT3406692 | Wiring Diagram |
| 2 | 8274261 | Panel, Rear Console |
| 3 | 3390646 | Screw, 8−18 x 5/16 |
| 4 | | Cap, End (L.H.) |
| | 8271365 | White |
| | 8271368 | Biscuit |
| 5 | 3936144 | Connector |
| 6 | 388326 | Screw, Console |
| 7 | 3395683 | Housing, Connector (Motor) |
| 8 | | Cap, End (R.H.) |
| | 8271359 | White |
| | 8271362 | Biscuit |
| 9 | 3400859 | Screw, Grounding |
| 10 | 339392 | Screen, Lint |
| 11 | | Cover, Lint Screen |
| | 8283378 | White |
| | 8283380 | Biscuit |
| 12 | 3978605 | Hinge, R.H. |
| | 3978606 | Hinge, L.H. |
| 13 | 688983 | Screw, 8−18 x 5/8 |
| 14 | 297535 | Bumper, Lint Lid |
| 15 | 693995 | Screw, Hex Head |
| 16 | | Top |
| | 8271390 | White |
| | 8271392 | Biscuit |
| 17 | 3394427 | Clip, Harness |
| 18 | | Knob, Control |
| | 8271339 | White |
| | 8271348 | Biscuit |
| 19 | 3405156 | Switch, Finish Guard |
| 20 | 3401075 | Resistor Assembly |
| 21 | 8299766 | Timer, 60 Hz. |
| 22 | 94614 | Terminal |
| 30 | 357213 | Nut, Push−In (2) |
| 31 | 3394302 | Harness, Wiring |
| 32 | 3399639 | Switch, Temperature |
| 33 | 3397695 | Wire, Jumper (Guard On/Off) |
| 34 | 694419 | Buzzer, Mini |
| 35 | 3396029 | Wire, Jumper (Temperature) |
| 39 | 3398095 | Relay, Push−To−Start |
| 40 | 3401144 | Connector (PTS Relay) |
| 41 | 3397269 | Connector (Timer) |
| 42 | 3347243 | Connector 6−Circuit |
| 48 | | Timer Knob Assembly |
| | 8312687 | White |
| | 8271404 | Biscuit |
| 53 | 8271418 | Bracket, Control |
| 54 | | Panel, Control |
| | 3977819 | White |
| | 3977820 | Biscuit |
| 73 | 3401684 | Wire, Jumper (Black) |

# LITERATURE AND OPTIONAL PARTS

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| **PAINT, TOUCH−UP (1/2oz.)** | | |
| | 72017 | White |
| | 4392899 | Biscuit |
| **PAINT, PRESSURIZED SPRAY (12 oz.)** | | |
| | 350930 | White |
| | 4392901 | Biscuit |
| | 350938 | Primer, Gray |
| **PAINT, BULK (1 qt.)** | | |
| | 799344 | White (Uncut) |
| | 4392900 | Biscuit(Uncut) |
| **Following May Be Purchased** | | |
| **DO−IT−YOURSELF REPAIR MANUALS** | | |
| | LIT677818 | Dryer |

# CABINET PARTS

**For Models: LER5644JQ0, LER5644JT0**
**(Designer White) (Biscuit)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

**For Models: LER5644JQ0, LER5644JT0**
**(Designer White) (Biscuit)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 2 | 3393008 | Screw, 10−16 x 1/2 |
| 3 | | Plug, Strike Hole |
| | 3403630 | White |
| | 3403632 | Biscuit |
| 5 | 3396795 | Cover, Terminal Block |
| 6 | 238614 | Bumper |
| 7 | 3396807 | Panel, Rear |
| 8 | | Plug, Hinge Hole (4) |
| | 3404413 | White |
| | 3404415 | Biscuit |
| 9 | 342055 | Screw, 8−18 x 1/2 |
| 10 | 3406104 | Door Switch Assembly |
| 11 | 697773 | Screw, 6−20 x 7/8 (2) |
| 13 | 693995 | Screw, Rear Panel Mounting |
| 16 | 3392100 | Foot, Dryer |
| | 279810 | Foot − Optional (Extended Length Package Of 2) (Not Included) |
| 17 | 343641 | Screw, 10−16 x 1/2 |
| 18 | | Cabinet (Includes Illus. Nos. 5, 7, 16, 29, 41 & 57) |
| | 3399580 | White |
| | 3399596 | Biscuit |
| 19 | 98234 | Clip, Ground |
| 20 | 690363 | Lock, Front Top (2) |
| 21 | | Front Panel Assembly |
| | 3403571 | White |
| | 3403576 | Biscuit |
| 23 | 685203 | Clip, Felt Pad |
| 24 | 690081 | Catch, Door |
| 28 | 3405514 | Hinge & Pin Assembly |
| 29 | 3394083 | Clip, Front Panel (2) |
| 33 | 3403431 | Strike, Door |
| 35 | 3403371 | Door, Rear |
| 36 | | Door Front |
| | 3403361 | White |
| | 3403363 | Biscuit |
| 37 | | Handle, Door |
| | 3405184 | White |
| | 3405189 | Biscuit |
| 38 | 349464 | Seal & Bearing Assembly |
| 40 | 279393 | Terminal Block Kit For Terminal Block |
| 41 | 3397659 | Block, Terminal |
| 51 | 238088 | Hinge, Top (2) |
| 53 | 3394332 | Idler & Slide Assembly |
| 56 | 8066065 | Belt, Drive |
| 57 | 348780 | Base, Motor |
| 58 | 3400500 | Bolt, 5/16−18 x 3/4 |
| 59 | 3394341 | Pulley, 60 Hz. |
| 62 | 3976707 | Motor Assembly 60 Hz. |
| 63 | 660658 | Clamp, Motor |
| 64 | 3404162 | Clamp, Motor (W/Shield) |
| 67 | 3405245 | Seal, Door |
| 87 | 697776 | Screw, 10−32 x 1/2 (External Ground) |
| 90 | 279318 | Terminal, Tinned & Brass (3) (Includes Illus. 40) |

# BULKHEAD PARTS

**For Models: LER5644JQ0, LER5644JT0**
**(Designer White) (Biscuit)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 694283 | Lint Chute Assembly |
| 4 | 3388703 | Washer, Support |
| 5 | 90767 | Screw, 8 x 3/8 |
| 6 | 3977393 | Thermal Cut−Off (Hi−Limit Thermostat Illus. No.15 Included) |
| 7 | 347139 | Seal, Lint Chute |
| 9 | 3392247 | Pad, Blower Housing |
| 10 | 694089 | Wheel, Blower |
| 11 | 3405016 | Housing, Blower |
| 12 | 3398161 | Clip |
| 13 | 343641 | Screw, 10−16 x 1/2 |
| 14 | 3397566 | Box, Heater |
| 15 | 3399693 | Thermostat, High Limit 250°F (121.1°C) (60 Hz.) |
| 16 | 3394196 | Seal, Blower Shaft |
| 17 | 3403585 | Element, Heater (For 240 Volt Installation) |
| 21 | 279457 | Wire Kit (For Heater Element Wiring Harness Repair) |
| 23 | 3392519 | Fuse, Thermal |
| 24 | 3387134 | Thermostat, Internal−Bias |
| 41 | 690997 | Ring, Tri |
| 42 | 3399506 | Shaft, L.H. |
| 43 | 3399507 | Shaft, R.H. |
| 44 | 3397588 | Roller, Support |
| 46 | 348197 | Washer, Support |
| 47 | 3359452 | Nut, 3/8−16 |
| 48 | 3397264 | Bulkhead |
| 62 | 3394509 | Ring, Bearing |
| 63 | 97787 | Screw, 11−16 x 7/8 |
| 66 | 8066085 | Seal, Rear Drum |
| 67 | 3396777 | Drum Assembly |
| 68 | 342847 | Baffle, Drum |
| 69 | 3976435 | Bracket, Support |
| 70 | 90296 | Clip |
| 73 | 339956 | Seal |
| 74 | 489463 | Screw |
| 75 | 696302 | Shield, Exhaust |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST